



PAINT STRAINER CONES



Fine mesh, 60x48, for filtering all pigmented finishes, Poly-Brush, Poly-Spray, varnish, and other liquids. Imprinted with Poly-Fiber logo.

P/N 11-22

TACK CLOTH



A treated cloth used as a very light wipe to attract and remove dust, lint, and static-charged particles from a surface just before spray painting.

P/N 11-33

SEWING NEEDLES

Curved:

3" and 6" for hand stitching
3" P/N 12-96 / 6" P/N 12-97



Straight:

12" and 18" rib lacing needles.
12" P/N 12-98 / 18" P/N 12-99



Curved Tip:

12" and 18" for the hidden rib lace knot.
12" P/N 13-21 / 18" P/N 13-22



PAINT STIRRING PADDLES



Polished wood, 12" length, 1" width. Imprinted with the Poly-Fiber logo.

P/N 13-25



DOPE AND GLUE BRUSHES



Glue Brushes: 1" wide, natural bristles and 3/8" wide, tin-plated tubular handle. Double crimped to hold the natural bristles.
3/8" Brush P/N T332 1" Brush P/N DB1

Dope Brushes: Best quality, well anchored natural bristles. Tested as best for Poly-Brush application. Beaver tail handle. 2", 3" & 4" widths.
2" P/N DB2 3" P/N DB3 4" P/N DB4

POLY-FIBER & CECONITE PROCEDURE MANUALS



The definitive Bibles for Poly-Fiber & Ceconite. A must to comply with the process. Easy to read and follow instructions and graphics. This manual can take even a complete novice through the entire process of covering a newly-constructed home-built or recovering a restored classic.

POLY-FIBER MANUAL P/N 11-PF

CECONITE MANUAL P/N 17-CMAN